

SANDURET 2
Microfine sandblaster

Order-No.: 14601

SANDURET 3
Microfine sandblaster

Order-No.: 14600

SANDURET 4
Microfine sandblaster

Order-No.: 14603



- for cleaning, buffing and polishing as well as for removing oxide layers from different surfaces
- available with two, three or four chambers
- heated chambers offer a constant flow of the abrasive
- precise and economic use of abrasives
- an additional nozzle removes abrasive material from the object with air pressure
- selector switch in chamber allowing quick change of abrasive
- refillable at any time by quick air release valve
- durable carbide nozzles

- safety glass panel with protective film
- extraction adapter on the side of the unit provides optimal visual conditions and glass protection
- foot switch
- REITEL quick-stop valve
- bright LED in the working area
- leather gauntlets
- water separator and filters avoid unnecessary maintenance and keep downtime to a minimum
- refilling and/or changing abrasive media can be done in just a few minutes by way of the separate drain screw
- optional drawer unit permits fast removal of abrasive material (see accessories, page 25)

Technical data

Line voltage	230V/50–60Hz
Current consumption	100W
Height	320 mm open: 480 mm
Width	480 mm
Depth	440 mm
Weight	17 kg
Air consumption	80l/min
Pressure	0,5–6 bar
Nozzles	1,2+1,5 mm
Particle size	25–250 μ
Housing	stainless steel

Line voltage	230V/50–60Hz
Current consumption	120W
Height	320 mm open: 480 mm
Width	480 mm
Depth	440 mm
Weight	18 kg
Air consumption	80l/min
Pressure	0,5–6 bar
Nozzles	0,8+1,2+1,5 mm
Particle size	25–250 μ
Housing	stainless steel

Line voltage	230V/50–60Hz
Current consumption	140W
Height	320 mm open: 480 mm
Width	480 mm
Depth	440 mm
Weight	19 kg
Air consumption	80l/min
Pressure	0,5–6 bar
Nozzles	0,8+1,2+1,5+1,5 mm
Particle size	25–250 μ
Housing	stainless steel

Recommendation

Optional drawer unit for SANDURET.

You will find this item and many other accessories, on pages 25/26 of our catalogue – such as the DUSTY COMFORT vacuum cleaner.

www.reitel.com/images/pdfs/REITEL-catalogue-2017_eng.pdf

Furthermore, the unit can be preconfigured according to required particle sizes.

For more detailed information, please contact our consulting and service hotline or our commercial partners.